

**3M™ Perfect-It™ Plus  
Foam Polishing Pad  
05738/4300-5017-3  
(1 pad, 8 in/20.3 cm)**

- Designed for polishing
- Convoluted foam face
- Inset backing for self-centering and edge protection
- High gloss finish

**To Install:**

1. Place the backup pad into the self-centering inset on the polishing pad.
2. Press firmly and twist to insure good contact with backup pad.

NOTE: Use caution around trim or moldings to avoid snagging or tearing the pad. Keep the pad flat, or nearly flat, on surface being compounded as angles can cause additional swirling.

**Note Illustrations:**



**Instructions for Use:**

1. Area to be compounded must be clean. Flush away all wet sanding residue. Thoroughly wipe surface with a damp cloth.
2. Recommended speed - 1800-2500 RPM. Do not exceed 2500 RPM. Use only with 3M™ Hookit™ SBS Backup Pad, Part No. 05717 or a 3M™ Perfect-It™ Backup Pad, Part No. 05718.

**Care and Cleaning Instructions:**

If the compounding pad becomes clogged, remove and install a clean pad. Clean clogged pad as follows: 1. Rinse in warm (up to 115° F) water. 2. Set wet pad face up on a flat surface and allow to dry.

**NOTE:** Rinse under water faucet. Do not use soap or cleaning solvents. Do not machine wash or dry. Do not clean pads with a buffing spur or screwdriver.

**Warranty and Limited Remedy:** This product will be free from defects in material and workmanship at the time of shipment. **3M MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** User is responsible for determining whether the 3M product is fit for a particular purpose and suitable for user's application. If this product is defective, your

exclusive remedy and 3M's and seller's sole obligation shall be, at 3M's option, to replace the product or refund the purchase price.

Covered by one or more of the following U.S. Patents:  
5,007,128; 5,185,964; 5,396,737.

3M Automotive Aftermarket Division  
3M Center/Bldg. 223-6N-01  
St. Paul, MN 55144-1000  
1-877-666-2277 (1-877-MMM-CARS)  
[www.3M.com/automotive](http://www.3M.com/automotive)

Made in U.S.A.

3M, Perfect-It and Hookit are trademarks of 3M Company.

© 3M 2005