



20100 FAST CURE URETHANE WINDSHEILD ADHESIVE

DIRECTIONS FOR USE:

1. To restore windshield to meet government standards clean glass with 20030 Triple Strength Glass Cleaner. Apply 20110 Pinchweld & Glass Bond Primer to glass & pinchweld and let dry.
2. Remove the steel seal and pierce a large hole on the nozzle end.
3. Apply a bead to pre-treated OEM pinchweld.
4. Position windshield into body opening and press into adhesive before the end of the tack free time.
5. Tools can be cleaned with 19002 General Purpose Adhesive Cleaner.

Tack free time: 30 minutes. Rate of cure at standard conditions (68°F (20°C) /50% Relative Humidity) 2mm/24 hours.

THIS PRODUCT REQUIRES MOISTURE IN THE AIR TO CURE.