



22106 PAINTABLE RUBBERIZED UNDERCOAT

DIRECTIONS FOR USE:

All substrates must be degreased and sanded. Surface must be free of rust, wax, silicone, grease, dirt and other contaminants. For best results, use when temperature of the can and surface is between 68°F and 75°F (20°C and 24°C).

1. Bare metal should be primed. Use 13100 Aerosol Self Etching Primer, or 13150 Epoxy Primer/Sealer.
2. Using a 26172 Siphon Gun at 50 to 80 psi, adjust air pressure and spray approximately 10 to 12" (25-30 cm) from surface. Distance and pressure at the gun will determine texture.

DRYING TIME: Approximately 2-3 hours.

CLEANING INSTRUCTIONS: Clean equipment immediately after use with 13602 Acrylic Lacquer Thinner.