




Index No.	Part No.	Description	No. Req.	Index No.	Part No.	Description	No. Req.
1	103132	Inlet Bushing	1	34	203134-1AA0	Bushing	2
2	103129-1AA0	Exhaust Deflector	1	35	203135-1EH0	Connector	2
3	103131-1AA0	Circlip	1	36	0810-HK0	Needle Bearing	2
4	203104	Rubber Protector	1	37	1612-HK0	Needle Bearing	2
5	203105-1PC0	Housing	1	38	203138-1GR0	Washer	1
6	O-1100-120	O-Ring	1	39	203139-1JB0	Screw	1
7	103126-1AA0	Valve Bushing	1	40	203140-1VW0	Spacer	2
8	O-0500-150	O-Ring	1	41	203141-1GR0	Connector Head	1
9	O-0500-200	O-Ring	1	42	203142-1GR0	Pin	2
10	103125-1JB0	Throttle Valve	1	43	203143-1JB0	Set Screw	1
11	103123-1AA0	Spring	1	44	203144-1PM0	Bushing	1
12	103122-1JB0	Air Regulator	1	45	203145-1MM1	Nut	1
13	O-0700-180	O-Ring	1	46	203146-1LL0	Extension Shaft	1
14	O-1100-250	O-Ring	1	47	203147-1JB0	Extension Housing	1
15	103119-1JB0	Valve Screw	1	48	203148-1PM0	Bushing	1
16	103127	Safety Lever	1	49	203149-1JB0	Blade Chuck	1
17	P-0030-220	Pin	1	50	203150-1JB0	Screw	2
18	0626-ZZ0A	Ball Bearing	1	51	203151-1JB0	Set Screw	1
19	103116-1DA0	Rear Plate	1	52	203152-1IB0	Work Guide	1
20	P-0025-060	Pin	2	53	203153-1JB0	Screw	2
21	103114-2GV0	Rotor	1	54	203154-1JB0	Nut	2
22	103115-1GR0	Rotor Blade	4	55	203155-1JB0	Screw	2
23	103112-1GR0	Cylinder	1	56	203156-1ED0	Blade Guide	1
24	103113-1JB0	Spacer	1	57	203157-1GS0	Blade 115L	1
25	P-0025-030	Pin	1	58	203158-1GS0	Blade 153L	1
26	103110-1DA0	Front Plate	1	59	203159-1GS0	Blade 203L	1
27	6000-ZZ0A	Ball Bearing	1	60	203160-1GR0	Piston	1
28	203128-1JB0	Spacer	1	61	O-3400-100	O-Ring	1
29	203129-1GR0	Spindle	1	62	203162-1AA0	Rear Cover	1
30	203130-1JB0	Housing Clamp	1	63	203163-1IB0	Blade Cover	3
31	203131-1PC0	Angle Housing	1	64	203164-1JB0	Wrench	1
32	O-1200-100	O-Ring	1	65	K-2031-1B	Blow Case	1
33	203133-1JB0	Screw	1				