


P/N	Description	Q'TY	P/N	Description	Q'TY	P/N	Description	Q'TY
1	Air Cap Set	1	13	Fluid adjusting Knob	1		20B Air Valve Packing	1
2	Fluid Nozzle	1	14	Air adjusting Assembly	1		20C Valve Body	1
3	Baffle	1		(For SJ-111A)			20D O Ring	1
5	Packing(For Needle)	1	14-1	Nut (For SJ-111)	1	20-1	Air Valve Assembly	
6	Needle Packing Seat	1	15	Screw, Trigger	1		(For SJ-111)	
7	Gun body	1	16	Stud, Trigger	1		20A Nut	1
8	Spreader Adjusting	1	17	Trigger	1		20B Packing	1
	Valve Set		18	Spring, Air Valve	1		20C Valve Body	1
9	Gasket, (Air Valve / Bushing)	2	19	Air Valve	1	21	Nipple	1
10	Housing	1	20	Air Valve Assembly	1		(Fluid Inlet, 3/8" NPS)	
11	Fluid Needle	1		(For SJ-111A)		22	Nipple	1
12	Spring (Needle)	1		20A Air Valve Packing Seat	1		(Air Inlet, 1/4" NPS)	


PAINT POT DIAGRAM(2QT-B)



PARTS LIST

Part No.	Description	Qty.	Part No.	Description	Qty.
810-01	Handle	1	810-08B	Cup (2 Qt.)	1
810-02	5/16 Hex Jam Nut	1	810-09	Screw	1
810-03	Fluid Outlet	1	810-10	Check Valve	1
810-04	Relief Valve Stem	1	810-11	Check Valve Bracket	1
810-05B	Cover Gasket	1	810-12	Check Valve Spring	1
810-06B	Cover	1	810-13	Regulator Assembly (S-081A) ...	1
810-07B	Fluid Tube (2 Qt.)	1			

PAINT POT DIAGRAM(2QT-S)



PARTS LIST

Part No.	Description	Qty.
810-01	Handle	1
810-02	5/16 Hex Jam Nut	1
810-03	Fluid Outlet	1
810-04	Relief Valve Stem	1
810-05S	Cover Gasket	1
810-06S	Cover	1
810-06-1S	Cover Nut	1
810-07S	Fluid Tube (2 Qt.)	1
810-08S	Cup (2 Qt.)	1
810-09	Screw	1
810-10	Check Valve	1
810-11	Check Valve Bracket	1
810-12	Check Valve Spring	1
810-13	Regulator Assembly (S-081A)	1