




AES 507 parts list on following page.


507

AES 507


PARTS LIST

Item No.	Description	Item No.	Description
1	Air Nozzle/HVLP	27	Material Sleeve
2	Ring	28	Plastic Cup
3	Air Cap/HVLP	28A	Adaptor
4	Fluid Nozzle/HVLP	29	Cover of 0.6 l Plastic Cup
5	Pacing screw for paint Needle	29B	Non-drip Control Device
6	Taflon Seal	30	Spanner
7	Washer	31	Socket Spanner
8	Screw	32	Brush
9	Ring	33A + B	Air Piston
10	Gasket	33F	Teflon Seal
11	Connector for 0.6 l Cup	33G	Nut
12	Gun Body	33H	Screw
13	Screw	34/H	Air Regulator
13C	Teflon seel		
13D	Bvoly		
13E	P. C. seal		
13F	Valve		
13G	Valve		
13H	Scrow		
14	Washer		
14A	Spray Regulating Screw		
14B	Spray Regulating Nut		
14C	O-Ring		
15	Control Knob		
15A	Countersunk Screw		
16	Paint Needle-Complete/HVLP		
17	Spring for Paint Needle		
18	Lockout for Fluid Control Knob		
18A	Fluid Control Knob		
23	Trigger		
24	Screw		
25	Pin		
26	Air Connection Piece 1/4" BSP/HVLP		
	Nozzle set (AES - 30166 1.4 mm AES - 30167 1.7 mm AES - 30168 2.0 mm)		
	Have to order complete set if special mark "※" !		

2082



AES-151 Spare Cup (Complete set)



AES-30176 Repair kit for spray gun

PARTS NO : 06 07 08 13C 13E
13H 14 14×4PC 33F 17

