Megliais. Wirror GLAZE

TECHNICAL BULLETIN

Cut & Polish Cream

A uniquely engineered cream for both compounding & polishing. This user-friendly product is the central component of the Solo™ System, a one-liquid polishing system for professional's who demand a simple approach to world class, swirl-free esults.

Part #: 1 Quart, part # M8632

1 Gallon, part # M8601

Packaging: 1 Quart, 6 per case

1 Gallon, 4 per case

Features: • Simple, one liquid system for both compounding and polishing

• Delivers revolutionary, swirl-free results with a one liquid system

Advanced Unigrit® Technology delivers "level cutting"
Use with Solo System buffing pads for best results
Specifically designed for paint and body shops

• Safe, VOC compliant formula

• PAINTABLE: Safe for use in the paint shop environment

pH: 8.0

Paintable: Yes

Dilution: RTU (Ready to use)

Application

Method: Rotary Buffer

Directions: Shake well. Work one section at a time. Always work on a cool, properly cured,

paint surface. Prepare the surface by using 1500 grit (or finer) DA dry sanding disks or 2000 grit (or finer) wet sanding paper by hand, such as our Unigrit

Finishing Papers.

Two step polishing system utilizes the same liquid for both steps.

<u>STEP 1 Defect Removal</u> – Set rotary buffer to approximately 1800 – 2000 RPM's. Choose appropriate Solo System buffing pad. To prime new or dry pads, lightly mist on M34 Final Inspection. Apply Cut & Polish Cream directly to properly cured paint finish, and begin working in a 2' x 2' area with overlapping passes. Continue working until defects and sanding marks are removed. Clean pad frequently.

<u>STEP 2 Final Polishing</u> – Set rotary buffer to approximately 1400 - 1800 RPM's. Choose appropriate Solo System buffing pad. To prime new or dry pads, lightly mist on M34 Final Inspection. Apply Cut & Polish Cream directly to paint finish, and begin working in a 2' x 2' area with overlapping passes. Continue working until swirl-free finish appears. Wipe remaining residue with a Meguiar's microfiber towel. Clean pad frequently. Optional: For extreme gloss, follow with a DA Polisher application of M80 Speed Glaze or your favorite Meguiar's polish with a Meguiar's foam pad.